

HƯỚNG DẪN SỬ DỤNG KTEL 117

ĐIỀU CHỈNH CHUÔNG LỚN / NHỎ

Gạt nút chỉnh âm lượng chuông ở đáy bàn máy sang vị trí “Hi” hay “Lo” hay “OF” để chọn mức chuông Lớn / Nhỏ hay tắt chuông.

CHỌN CHẾ ĐỘ TONE/PULSE (T/P)

Gạt nút T/P ở đáy bàn máy sang vị trí “T” hay “P” để chọn chế độ quay số Tone hay Pulse. Nếu chọn “P”, khi số số gọi đi sẽ nghe tín hiệu “tạch tách”). Xin liên hệ tổng đài công ty đăng ký thuê bao điện thoại địa phương để biết thêm chi tiết.

GOI LAI SỐ CUỐI (REDIAL)

Để gọi lại (lặp lại) số điện thoại máy vừa gọi đi trước đó, nhấc tay nghe và nhấn phím REDIAL.

TẠM NGẮT PHÁT (MUTE)

Trong lúc đang đàm thoại có thể nhấn và giữ phím MUTE để tạm ngắt micro phát tiếng của người sử dụng (tác dụng như dùng tay chặn kín đầu nói của tay nghe, vì vậy người nghe bên kia sẽ không thể nghe gì). Khi không giữ phím MUTE, thì bên kia có thể nghe bình thường.

TẠM NGẮT MẠCH (FLASH)

Có thể dùng phím FLASH để ngắt mạch nhanh (chuyển máy trong tổng đài nội bộ) hay dùng cho các dịch vụ cộng thêm sau khi đăng ký tại công ty điện thoại địa phương (như dịch vụ giữ đợi cuộc gọi).

ĐÈN BÁO MÁY ĐANG SỬ DỤNG (IN-USE)

Đèn In-use bật sáng khi tay nghe được nhấc lên hay khi tay nghe không được lại đặt đúng vị trí trên bàn máy.

INSTRUCTION MANUAL OF KTEL 117.

RINGER VOLUME CONTROL

Ringer volume can be adjusted in 3 steps from High to Low and Off position as desired by sliding the switch at bottom of base unit to “H”, “L” or “OF”.

TONE/PULSE SWITCH (T/P)

Slide the switch T/P at bottom of base unit to “T”, or “P” to dial in mode Tone or Pulse.

REDIAL

The telephone automatically stores the number dialled in memory. To dial the same number again, simply press the hook switch to get the dial tone and then press the REDIAL button.

MUTE

Press and hold the key MUTE while on conversation then the other party can not hear you. If you release the key MUTE, then the other party can hear you again.

FLASH

Flash works as hook knob (useful to transfer a call if you are using a pabx system). This is also useful for call waiting or other services provided by telephone company.

IN-USE INDICATOR

The LED indicator will light up while handset is picking up or in case handset is not placed in right position on base (and your line is engaged/ busy).